


# MECHANICAL MOVEMENT

## INSTRUCTION MANUAL

### DISPLAY



### Phases of Second Hand Counter



\*Second hand counter position may be located at different position depends on models.

#### A) Winding the mainspring

To initiate the power reserve the watch must be wound manually turning the crown in "A" position, in a clockwise direction for about 25 revolutions. This start up wind is usually sufficient for most mechanical watches.

#### B) SETTING THE TIME

1. Pull the crown out to "B" position.
2. Turn the crown to set hour and minute hands.
3. Push the crown back to the normal position.