

QUARTZ (3-Hand Date Models)

Includes all models with an hour,
Minute and second hand and date at 3:00, 4:00, 6:00 or 9:00 o'clock.

A) DISPLAYS AND BUTTONS




FIGURE 1

Date in different Phase



FIG 1.1



FIG 1.2



FIG 1.3

***Date or Day of the week window may be located at different position depends on the models.**

B) TO SET THE TIME

- 1) Pull out crown (unscrew) to second click position – C.
- 2) Turn crown to correct time.
- 3) Push in crown to A to set.

C) TO SET THE DATE

This applies to all models with date windows at 3:00, 4:00, and 6:00 or 9:00 o'clock.

- 1) Pull out crown to first click position – B
- 2) Turn crown counter-clockwise to correct date.
- 3) Push in crown to A to set.